


## **Software protection**

Depending on the type of machine, it is provided with a number of software protections. The software looks at all inputs and outputs of the machine during the entire process. If situations arise that are not allowed, the software intervenes. This intervention usually results in the machine being switched off and a malfunction message by quickly blinking of the green LED in the left selection button. For possible solutions to this malfunction message, see the malfunction list alongside.



*Error message: quickly blinking green LED in left selection button*

The green LED in the left selection button is blinking **slowly**.

- The machine is busy with filling, heating, dosing or rinsing.

### *Malfunction message:*

The green LED in the left selection button is blinking **quickly**. There is a malfunction at:

- The water supply:  
If the process of filling the float tank takes too long, whatever reason, the machine switches off.
- The boiler heating:  
If the temperature sensor is broken or the temperature rises above 97 °C, the machine switches off.

Remove the plug from the wallsocket and put it in again. If after that the green LED is still blinking quickly, remove the plug again.